



Ceiling Cladding Installation

BEFORE INSTALLATION

The structure of the roof needs to be level (even and straight). Room temperature must be between 15-30°C and the relative humidity must be between 30-50% within the structure at normal living conditions.

PREPARATION

Wood battens 38x38mm must be drilled directly into the structure of the roof beams at 400mm apart. The anchor line (straight line) needs to be set before the ceiling cladding work takes place so that all timber runs straight.

INSTRUCTIONS

The Oggie board will get nailed and glued directly onto the wooden battens. A 10-15mm expansion gap is needed around the perimeter of the ceilings. Areas that are longer than 10 meters in length and 8 meters in width will require an expansion gap. The expansion gap can be covered with a trim (quadrant, flat strip or soft joint).

HANDOVER

When installation is completed, the walls are to be cleaned and maintained using the correct products for the specific floor finish. The WOCA Soaps can be purchased from any Oggie showroom.

CONTACT US

CAPE TOWN
37 Paarden Eiland Rd
Paarden Eiland

+27 (0) 21 510 2846

JOHANNESBURG
3 Desmond Street
Kramerville, Sandton

+27 (0) 11 262 3117

DURBAN
Shop 6 – Beacon Rock
21 Lighthouse Road,
Umhlanga

+27 (0) 31 000 1000

enquiry@oggie.co.za

www.oggieflooring.com