



## BEFORE INSTALLATION

The walls need to be level (even and straight). Room temperature must be between 15-30°C and the relative humidity must be between 30-50% within the structure at normal living conditions.

## PREPARATION

Wood battens (32x32mm) must be drilled directly into the wall 400mm apart. The anchor line needs to be set before the cladding takes place so that all the timber runs straight.

## INSTRUCTIONS

The Oggie board will get nailed and glued directly on top of the wood battens or ply board (18mm ply board is recommended if needed). A 10-15mm expansion gap is needed around the perimeter of the wall cladding. Areas that are longer than 10 meters in length and 8 meters in width require an expansion gap. The expansion gap can be covered with a trim (quadrant, flat strip, soft joint).

## HANDOVER

When installation is completed, the walls are to be cleaned and maintained using the correct products for the specific floor finish. The WOCA Soaps can be purchased from any Oggie showroom.

## CONTACT US

CAPE TOWN  
37 Paarden Eiland Rd  
Paarden Eiland

+27 (0) 21 510 2846

JOHANNESBURG  
3 Desmond Street  
Kramerville, Sandton

+27 (0) 11 262 3117

DURBAN  
Shop 6 – Beacon Rock  
21 Lighthouse Road,  
Umhlanga

+27 (0) 31 000 1000

[enquiry@oggie.co.za](mailto:enquiry@oggie.co.za)

[www.oggieflooring.com](http://www.oggieflooring.com)